



Technical Rider (Stand 2018_03)

- FOH-Mixer Kanalbelegung -

Kontakt: Arnd Jünemann
Mobil: +49 171 659 2847
E-Mail: arnd.juenemann@t-online.de

| Channel-Nr. | Signal | Artist | Mikrophon/DI | + 48 V | Stativ | Insert | Remarks |
|-------------|----------------------|---------|-------------------------------|--------|--------|------------|--------------------------------|
| 1 | Bassdrum | Axel | Sennheiser E 901; E 902 o.ä. | | Klein | Gate | |
| 2 | Snare | | Shure SM 57/Sennheiser E 604 | | Klein | Compressor | |
| 3 | HiHat | | Shure SM 57/Sennheiser MD 421 | | Klein | | |
| 4 | Tom 1 | | Sennheiser E 604 o.ä. | | Clip | Gate | |
| 5 | Tom 2 | | Sennheiser E 604 o.ä. | | Clip | Gate | |
| 6 | Tom 3 | | Sennheiser E 604 o.ä. | | Clip | Gate | |
| 7 | Floortom 1 | | Sennheiser E 604 o.ä. | | Clip | Gate | |
| 8 | Floortom 2 | | Sennheiser E 604 o.ä. | | Clip | Gate | |
| 9 | Overhead -L- | | AKG CK 391 o.ä. | X | Groß | | |
| 10 | Overhead -R- | | AKG CK 391 o.ä. | X | Groß | | |
| 11 | Bassguitar | Uwe | DI-Out Amplifier | | | Compressor | |
| 12 | Guitar 1 -Electric- | Peter | Shure SM 57/Sennheiser MD 421 | | Klein | | |
| 13 | Guitar 1 -Acoustic- | | DI-Box | X | | Compressor | |
| 14 | Guitar 2 -Electric- | Stephan | DI-Out Amplifier | | | | |
| 15 | Guitar 2 -Acoustic- | | DI-Box | X | | Compressor | |
| 16 | Keyboard 1 -Piano- | Arnd | DI-Box | | | | Yamaha CP 300 (Mono) |
| 17 | Keyboard 2 -Hammond- | | DI-Box | | | | Hammond XK3c (Mono) |
| 18 | Saxophon | Guest | Sennheiser MD 421/MD 441 o.ä. | | Groß | Compressor | |
| 19 | Bluesharp | Guest | Shure SM 57 o.ä. | | Klein | Compressor | Shure 520 DX via Amplifier |
| 20 | Vocals 1 (Keyboard) | Arnd | Sennheiser E 945 | | Groß | Compressor | |
| 21 | Vocals 2 (Guitar 1) | Peter | Shure PG 58/Shure SM 58 | | Groß | Compressor | |
| 22 | Vocals 3 (Guitar 2) | Stephan | Shure SM 58 | | Groß | Compressor | |
| 23 | Vocals 4 (Drums) | Axel | Shure Headset | | | Compressor | |
| 24 | Vocals 5 (Guest) | NN | Shure SM 58 | | Groß | Compressor | |
| 25 | FX1 Reverb | | | | | | Lexicon; Yamaha, TC Electronic |
| 26 | FX1 Reverb | | | | | | Lexicon; Yamaha, TC Electronic |
| 27 | FX2 Delay | | | | | | Lexicon; Yamaha, TC Electronic |
| 28 | FX2 Delay | | | | | | Lexicon; Yamaha, TC Electronic |
| 29 | CD Input | | | | | | |
| 30 | CD Input | | | | | | |
| 31 | | | | | | | |
| 32 | | | | | | | |